



1. You will know if you need to update your 2178/BHT-2 if the unit displays anything lower than U 1.3 upon power up.
2. Download the 2178 software update from the link below.

[https://www.farmscanag.com/exe/exe/Baler\\_update.zip](https://www.farmscanag.com/exe/exe/Baler_update.zip)

3. Unzip and install the update by running the setup.exe file. Once installed, an AgraTronix icon will appear on your desktop.
4. Double-click the icon to run the update program.
5. Connect the 2178 to the supplied USB cable and then to your computer.
6. Once the program recognizes the 2178/BH-2 tester the program will display device attached.
7. Now in the program, click the open hex file button and select the file "Baler\_V\_1\_3.Hex".
8. Click on the program/verify button to begin the updating process.
9. Once the programming is complete, the program will display that the update was successful.
10. You can now remove the USB cable.
11. On power up the BHT-2 unit should now display U 1.3. The unit is updated.

NOTE: If you have any errors running the update program you may need to install ".NET" on your computer. This is a safe program to install and is free from Microsoft: [Microsoft .NET Framework](http://www.microsoft.com/downloads/en/details.aspx?FamilyId=333325fd-ae52-4e35-b531-508d977d32a6&displaylang=en) (<http://www.microsoft.com/downloads/en/details.aspx?FamilyId=333325fd-ae52-4e35-b531-508d977d32a6&displaylang=en> )